

# SPORTSMAN ACE BIMINI ROOF KIT

P/N 2879692

Application

**SPORTSMAN ACE**



Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

## Kit Contents:

<u>Qty</u>	<u>Part Description</u>	<u>Part Number</u>
1	Cover	2879692
2	Plastic Lock & Ride Clamp	2878747
1	Instructions	9924914

## Tools Required:

Screwdriver

Tape Measure

**APPROXIMATE ASSEMBLY TIME:** 15-20 minutes

**IMPORTANT:** Your Polaris SPORTSMAN ACE BIMINI ROOF is exclusively designed for your vehicle. Please read the installation instructions thoroughly before beginning. Installation is easier if the vehicle is clean and free of debris. For your safety and to ensure a satisfactory installation, perform all installation steps correctly and in the sequence shown. Please wear safety glasses while performing the steps in the following instructions.



## INSTALLATION INSTRUCTIONS:

**IMPORTANT:** Prior to installing the roof to the vehicle, be sure to install rear panel, map bag, rear view mirror and audio kits if you have purchased them.


1. Place the vehicle in "PARK". Turn the key to "OFF" position and remove from the vehicle.
2. a. If you are not using a full front windshield, attach roof clamps to roof by installing two screws on the four sides of the roof. Loosely tighten screws. Figure 1.  
b. If you have a full front windshield, install the windshield onto the vehicle. Remove four screws from top two clamps, but leave clamps installed on the ROPS. Secure roof to outside of windshield similar to what is shown in Figure 1 using screws removed in this step. Skip Steps 3 and 4 if installing with a full windshield.



3. Place roof panel on top of ROPS frame. Clamp roof in place.
4. At the front of the vehicle, pull the roof forward, making sure the roof clamp is 23.5" from the bottom of the vehicle rack. Figure 2 and Figure 3.
5. Tighten all clamp screws.



6. At the rear of the machine, wrap the roof strap around the lower ROPS bar and back up to the buckle as shown in Figure 4 and tighten roof until it fits snugly over the ROPS structure.



7. Loop the strap through the buckle as shown in Figure 5 to secure the tails of the straps. Repeat this for both LH and RH side of the roof.

