

RGR Economy Rear Panel

KIT PN 2878165 & 2204452

Application Polaris RGR



Before you begin, read these instructions and check to be sure all parts and tools are accounted for. Please retain these installation instructions for future reference and parts ordering information.

Kit Components:

<u>QTY.</u>	<u>Part Description</u>
1	Upper Rear Panel
1	Lower Rear Panel
2	Square Clamp
6	Round Clamp
12	¼-20 x 1" Pan Head Screw
12	Fender Washer
12	Nylock Flange Nut
12ft	Adhesive foam

IMPORTANT: Your Polaris accessory kit is exclusively designed for your Polaris vehicle. Please read the installation instructions and operator's manual thoroughly before beginning. Installation of any item is easier if the vehicle is clean and free of debris. **Approximate Installation Time:** 30 Minutes

INSTALLATION INSTRUCTIONS

1. Install foam on the inside of the lower section of the upper rear panel as shown below.
2. Note the direction of the lower rear panel as illustrated below. Overlap the upper rear panel over the lower rear panel. Insert (4) pan head screws and (4) fender washers through the holes in the upper rear panel and lower rear panel. Fasten using (4) nylock nuts.
3. Apply adhesive foam along both sides of the inside of the rear panel. This will prevent excessive rattling/vibration.
4. Align the assembled rear panel with the rear frame of the vehicle. Install (2) round clamps over the top cab frame tubing as illustrated. Insert (2) pan head screws and (2) fender washers through the mount holes in the upper rear panel, and into the clamps. Fasten using (2) nylock nuts.
5. Install (2) square clamps on the frame in the center of the rear panel as illustrated. Fasten using (2) pan head screws, (2) fender washers, and (2) nylock nuts.
6. Install the remaining (4) clamps over the cab frame tubing. Insert (4) pan head screws and (4) fender washers through the mount holes in the rear panel, and into the clamps. Fasten using (4) nylock nuts.
7. Tighten all hardware.

Note: The bottom clamps may be difficult to install, as the lower portion of the rear panel overhangs onto the vehicle frame.

IMPORTANT: Do not use glass cleaners and solvents such as ammonia, alcohol, and petroleum distillates.

Maintenance: Periodically check all fasteners for tightness and re-torque as required.

Cleaning:

1. Use an indirect high pressure water supply to rinse the large dirt particles from the rear panel.
2. Once the majority of dirt is removed, use warm soapy water and a cotton terry cloth to wash all rear panel components.
3. Rinse thoroughly and allow to air dry.
4. Use a quality polish such as Plexus® or Novus II® to clean and remove fine scratches from the rear panel.

